




Caution

Removal of the cover exposes Dangerous Voltages. Turn off the power at the Main breaker (shore power) before proceeding.

Remove this screw on the PD4135. #2 square drive



Remove this screw on the PD4045 or PD4060 . #2 square drive



Insert a flatblade screwdriver in the slot and twist it .

The cover will snap back on. Then replace the screw.



Cover-Removal-PD4000- PD4100

