

Wizard or Pendant Operation Revised 09/11/2017

*To determine The Wizard version, press the button once.
 If it remains solid you have a Wizard 1
 If it blinks every 8 seconds you have Wizard 2*

WIZARD 1			
Action	Automatic & Manual operation are the same	Mode	Converter output
Press the button once.	The light should go solid	Boost	This is Boost mode 14.4VDC
Press and hold the button until it blinks and let go .	Will blink on and off 1-5 times a second.	Regular mode	This is regular mode 13.6 VDC.
Press and hold the button again until it stops flashing fast. (light will be out) Let go of the button.	The light will blink briefly every 5-8 seconds	This is the storage mode	This is storage mode 13.2VDC.

WIZARD 2				
Action	Automatic	Manual	Mode	Converter Output
Press the button once.	The light should go solid	The light will go solid and blink once every 8 seconds.	Boost	14.4 Boost mode
Press and hold the button until it blinks and let go .	Will blink on and at a 1 second rate.	Will flash on and off at a 1 second rate.	Regular mode	This is regular mode 13.6 VDC.
Press and hold the button again until it stops flashing fast.	(light will be out) Let go of the button. This is the storage mode the light will blink briefly every 5-8 seconds	Light will be off and double flash every 8 seconds	This is the storage mode	The output will be 13.2VDC.